


Click for latest document version conwed.com/details-eurospan-w













B FLUSH MOUNT DETAIL HALF SCALE

C INSIDE CORNER DETAIL
HALF SCALE












2
















H TYPICAL WINDOW/DOOR CASING DETAIL (PLAN VIEW)

HALF SCALE





































7




























TYPICAL @ SPRINKLER HEAD

HALF SCALE







11








2 INCH FULL END WRAP-0"








13





























TYPICAL @ BASE / TRIM (SECTION)























OUTSIDE CORNER DETAIL (PLAN VIEW)











800 1445 Holland Rd Maumee, OH 43537

866-708-1727

## **Painting Track Eurospan Acoustical System**

cover the color of the track. For most installations, painting is not necessary. Contact Conwed for more information. white fabrics that may not Eurospan track can be painted in unique circumstances such as using light weight black or

To paint Eurospan track, it is extremely important to properly prepare the surface and use the correct paint.

### **Materials:**

- 220 grit sandpaper
- Acetone

419.871.9084

- Drop cloths and any other supplies to prevent overspray contamination to surrounding areas
- Protective eyewear, dust mask, and gloves
- Spray paint in an appropriate color suitable for plastic surfaces such as Rust-Oleum 2X Ultracover

### 1Preparation

- Protect surrounding area from overspray
- Be careful not Lightly scuff the track with 220 grit sandpaper. A light scuff on all surfaces is all that is required. to over sand surfaces that might change the profile of the track.
- One quick wipe with a clean rag and Clean the track surface with acetone applied to a rag and wiped down. acetone is all that is required.

### Painting

- Place track on a flat surface with the bottom of the mounting flange down. In most circumstances, it is not necessary to paint the bottom of the flange.
- Apply spray paint per the manufacturer's recommendations in several light coats.
- Allow the paint to dry at least 24 hours before attempting to install and tuck fabric.

## Special Care During Installation

When properly dry, the painted surface should be reasonably resistant to scuffs and scratches. If a scratch does a quick touch up with the paint prior to installing fabric should fix the issue. occur,

23

866-708-1727

## **Fasteners Eurospan Acoustical System –**

These listed screws are recommended, but equal or similar screws are fine. Some substrates such as steel or masonry may require different fasteners. Contact Conwed for more information.

- For fastening fabric tracks– install screws approximately every 2" –3" to prevent the track from flexing. Staples should be spaced no more than 1" apart.
- approximately 16" on center in a square pattern. When fastening fiberglass, only drive the screw so that a For fastening 1" and 2" nominal acoustical fiberglass board to walls and ceilings- install screws at slight depression in the fiberglass is formed. Do not over tighten.

Note: Adhesive is usually NOT necessary, it can be used in certain installations if mechanical fasteners are not appropriate

## -Fastening track to drywall

<b>Bugle Head GRABBER®</b>	INTERIOR WOOD Drywdll	PART NO.	SIZE	WEIGHT	QTY	PART NO. SIZE WEIGHT QTY DESCRIPTION
•	Attaches gypsum board and wood to wood. Extra sharp	100	6 x 1-in	29-lb	10M	10M BUGLE HEAD, #2PHIL, COARSE THREAD, GRAY PHOSPHATE
	point and threads make driving easier and provide	200	6 x 1-1/8-in	32-lb	10M	BUGLE HEAD, #2PHIL, COARSE THREAD, GRAY PHOSPHAT
	better holding power.	300	6 x 1-1/4-in	33-lb	8M	BUGLE HEAD, #2PHIL, COARSE THREAD, GRAY PHOSPHATE
	Bugle head	400	6 x 1-5/8-in	22-lb	SM.	BUGLE HEAD, #2PHIL, COARSE THREAD, GRAY PHOSPHAT
	· Coarse thread	200	7 x 2-in	21-16	3.5M	3.5M BUGLE HEAD, #2PHIL, COARSE THREAD, GRAY PHOSPHAT
(2	No. 2 Phillips	009	7 x 2-1/4-in	20-lb	3M	BUGLE HEAD, #2PHIL, COARSE THREAD, GRAY PHOSPHATE
(72)	ordy phosphare	006	8 x 2-1/2-in	25-lb	2.5M	BUGLE HEAD, #2PHIL, COARSE THREAD, GRAY PHOSPHAT
)		1100	8 x 3-in	22-lb	2M	BUGLE HEAD, #2PHIL, COARSE THREAD, GRAY PHOSPHATI
		1200	10 x 3-1/2-in	17-lb	M	BUGLE HEAD, #2PHIL, COARSE THREAD, GRAY PHOSPHATE
		****		11 00	ŀ	Section of the sectio

# -Fastening track to drywall with pneumatic stapler



18 Gauge x 1" construction staples


## -Fastening track to drywall with steel backer


Bugle Head Streaker®   LIGHT GAUGE MATAL Drywoll   PART NO. 5128 W41GHT 0TY 055GRIPPION   PART NO. 5248 W41GHT 0TY 0TY 055GRIPPION   PART NO. 5248 W41GHT 0TY 0TY 0TY 0TY 0TY 0TY 0TY 0TY 0TY 0T							
Manches graum board to wood or 25-20 gus steel.   166   6 x 1-in   29-16   10M	<b>Bugle Head Streaker®</b>	LIGHT GAUGE METAL Drywall	PART NO.	SIZE	WEIGHT	QTY	DESCRIPTION
Standard bagic head		Attaches avasum hoard to wood or 25-30 on steel	168	6 x 1-in	29-Ib	10M	10M BUGLE HEAD, #2PHIL, FINE THREAD, GRAY PHOSPHATE
Bugle head     Fire thread     Fire thread     For philips     For philip	-	Standard bugle head.	268	6 x 1-1/8-in	32-lb	10M	BUGLE HEAD, #2PHIL, FINE THREAD, GRAY PHOSPHATE
- Fire three fire thre			368	6 x 1-1/4-in	30-Ib	8M	BUGLE HEAD, #2PHIL, FINE THREAD, GRAY PHOSPHATE
Mo.2 Publiss         768         6 x 2-in         22-ib         3.5M           Gray phosphate         848         7 x 2 //4-in         20-ib         3.M           948         8 x 2 //17-in         20-ib         2.5M           1168         8 x 2 //17-in         20-ib         2.5M           174         184         8 x 3 //17-in         20-ib         2.5M           174         174         174         174         174         174		• Bugle head	468	6 x 1-5/8-in	22-lb	SM.	BUGLE HEAD, #2PHIL, FINE THREAD, GRAY PHOSPHATE
• Gray phosphate 868 7 x 2 1/4-in 20-4b 3M 968 8 x 2 1/2-in 20-4b 2.M 1166 8 x 3 in 22-4b 2.M 1748 in x 21-3b 2.M		• No. 2 Phillips	768	6 x 2-in	22-Ib	3.5M	BUGLE HEAD, #2PHIL, FINE THREAD, GRAY PHOSPHATE
948 8 12-1724	(	Gray phosphate	898	7 x 2-1/4-in	20-lb	3.8	BUGLE HEAD, #2PHIL, FINE THREAD, GRAY PHOSPHATE
8 x 3-in 22-lb 2M	(57.5)		896	8 x 2-1/2-in		2.5M	BUGLE HEAD, #2PHIL, FINE THREAD, GRAY PHOSPHATE
10 v 3.1/2.in 17.1h 1M	)		1168	8 x 3-in	22-lb	2M	BUGLE HEAD, #2PHIL, FINE THREAD, GRAY PHOSPHATE
			1768	10 v 3.1/2.in		11/1	RIIGIE HEAN #9PHII FINE THREAN GRAY PHINCPHATE


# -Fastening 1"-2" fiberglass acoustical board to drywall



©2026











A TYPICAL @ RETURN PERIMETER EUROSPAN® CEILING / CLOUD (DRY WALL GRID) HALF SOALE


B TYPICAL @ PERIMETER WALL
(1.5GRD) (DRY WALL GRID) HALF SCALE













31











### **CONWED**

1445 HOLLAND RD. MAUMEE, OH 43537 PH: 419-866-7705

JOB NO	
SCALE:	6" = 1'-0"
DRAWN BY:	СМК
CHECKED:	
DATE:	
REV:	
REV:	


### GENERAL EUROSPAN DETAILS


**D.1** 

DTLS

SHEET 1 of 9

**32** 






A 1.5<sub>GYP</sub>


TYPICAL @ RETURN PERIMETER EUROSPAN\* CEILING / CLOUD WITH BLOCKING

SCALE: N.T.S.

B EDGE AT WALL / SOFFIT WITH BLOCKING

SCALE: N.T.S.







FLUSH MOUNT DETAIL WITH BLOCKING

SCALE: N.T.S.

TYPICAL MIDSEAM JOINT WITH BLOCKING

SCALE: N.T.S.








### FULL EDGE WRAP FINISHED END WITH BLOCKING

SCALE: N.T.S.

OUTSIDE CORNER DETAIL WITH BLOCKING


SCALE: N.T.S.

1.5gyp/



INSIDE CORNER DETAIL WITH BLOCKING


1.5gyp/ SCALE: N.T.S.



TYPICAL @ PLANE CHANGE WITH BLOCKING .**5**gyp/ SCALE: N.T.S.


v 5.0.00 CONWED 1445 Holland Rd., Maumee, OH 43537 419.871.9084 conwed.com ©2026 Conwed 36

Η






NOTE: EUROSPAN CEILINGS DO NOT REQUIRE BLOCKING AT SMALL CIRCULAR CEILING PENETRATIONS. EUROSPAN FABRIC IS SELF SUPPORTING. OPENINGS ARE TO BE CUT AFTER STRETCHED INTO PLACE.





NOTE: EUROSPAN CEILINGS DO NOT REQUIRE BLOCKING AT SMALL CIRCULAR CEILING PENETRATIONS. EUROSPAN FABRIC IS SELF SUPPORTING. OPENINGS ARE TO BE CUT AFTER STRETCHED INTO PLACE.





EUROSPAN® @ TYPICAL RECESSED LIGHT WITH BLOCKING

SCALE: N.T.S.

v 5.0.00 CONWED 419.871.9084 conwed.com ©2026 Conwed

CONWED

v 5.0.00

## **Mounting Details: Eurospan® Access**

### I. Notes

ordered to size and must be installed on site with the rest of the system. Access doors can be used either safety cables prevent the door from falling. The safety cables can be unhooked with carabiners and the for ceilings or walls. The doors can be released with a hidden push to unlatch system. Once unlatched, Eurospan® Stretch Acoustic System can be supplied with access doors. Access doors can be custom door removed completely.

### II. Materials

1445 Holland Rd., Maumee, OH 43537

- · Blocking as necessary to mount doors at correct height/depth
- ·Acetone
- · Rags, scissors
- Spray contact adhesive such as 3M spray 77
  - · Protective eyewear, dust mask, and gloves

### III. Installation

419.871.9084

- 1. Mount access door to opening using appropriate blocking to make the bottom of the door at the same height as the Eurospan fabric ceiling.
- Be sure surrounding acoustical insulation covers the flange of the access door when installed
- Remove access door from frame and set aside. Clean all aluminum surfaces with acetone. М.
- tucking around the perimeter, cut an x in the fabric from corner to corner of the opening staying 2 inches 4. When covering the ceiling or wall, stretch the fabric over the panel opening. Before doing the final from the aluminum frame.

conwed.com

- Prepare the fit of the fabric inside the frame by using scissors and making small cuts till a tailored look is achieved. 5.
- 6. Using spray contact adhesive (3M spray 77 recommended) apply liberally to both the vertical frame surface and fabric. Allow the adhesive to get tacky before pulling and tailoring the corners.
- 7. Trim off excess fabric.


©2026

8. Cover the access door with fabric using the same method. Be sure the fabric direction matches the surrounding material.


## See next page for Mounting Detail Diagram

Conwed

Disclaimer: The following are guidelines given in good faith to help avoid common errors. They are not intended to be a step-by-step list of instructions or a checklist, and it is assumed the installer has general construction knowledge. Conwed bears no responsibility for any installation actions taken or not taken, and is not responsible for installer selection.



ESS @ WALL PENETRATION - PLAN DETAIL SCALE: N.T.S. RE: ARCH SHEET N/A



CONWED 1445 Holland Rd., Maumee, OH 43537

SCALE: N.T.S.

419.871.9084

conwed.com

©2026

Conwed

41